LUCID DOOR

















How To Change Lock Code

Initial Lock Code: 000

1. Locate the hole on the bottom of the lock.

2. Insert a thin object, such as a paperclip, into the hole and keep it inserted throughout the entire code-changing process.

3.Select a new code, then remove the thin object.

4. Scramble the lock.

Note: Be sure to remember your new code.
You may repeat these steps at any time using a thin object to reset the code.